

How to cast your ballot using Verity Touch with Access



1 Use one of the following tools:

Move wheel and **Select** button



Jelly switches
(or your sip-and-puff)



Touch screen



Note: If you want to listen to instructions and ballot choices, use headphones or a neckloop.

2 Select each choice; then select **Next** to move to the next contest.



3 Review your ballot carefully to confirm your selections.



4 Select the **Cast ballot** button. A waving American flag appears, indicating success!

